



55D.

The insufficient engine oil level warning light stays off even when fluid level is lower than normal.



The insufficient coolant level warning light stays on even when fluid level is normal.



The insufficient coolant level warning light stays off even when fluid level is lower than normal

